

Manual iAQ-core test samples

Indoor Air Quality sensor module for consumer applications

- I²C interface
- SMD type package
- Reflow capable




Product summary

The iAQ-core is used to measure VOC levels and provide CO₂ equivalent predictions. The data is available via I²C bus.

The sensor itself is protected by a plastic cap and a filter membrane. The sensor module can be soldered directly to a host circuit board with selective or reflow soldering via the edge connectors. The sensor is protected by a membrane, which should not be removed.

! *Note: Please read the I²C addressing instructions carefully. An undefined use of the I²C interface could harm the iAQ-core module and cause a loss of functionality.*

Dimensions



| Pin | Name | Comment |
|-----|------|-------------------------------|
| 1 | NC | Not connected |
| 2 | SCL | I ² C serial clock |
| 3 | GND | Ground |
| 4 | SDA | I ² C serial data |
| 5 | NC | Not connected |
| 6 | VCC | +3.3V |

Figure 1: iAQ-core sensor (dimensions in mm, Top View)

| | |
|--------------------------------------|-----------------------------|
| Dimensions (approximate values) | PCB 15.24 x 17.78 x 1.7 mm |
| | CAP 11.2 x 17.78 x 2.6 mm |
| | TOTAL HEIGHT 4.3 mm |
| Sensor position (approximate values) | 7.6 x 12.3 mm |
| | Radius 3.5 mm |
| Weight | Approximately 1g |
| IP-Class | 00 (at proper installation) |
| Connector | Card edge (cut via) |

Contents

| | | |
|----------|---|----------|
| 1 | ELECTRICAL SPECIFICATIONS | 3 |
| 1.1 | POWER SUPPLY | 3 |
| 1.2 | COMMUNICATION | 3 |
| 2 | ENVIRONMENTAL SPECIFICATIONS | 3 |
| 3 | SENSOR FEATURES | 3 |
| 4 | PC INTERFACE | 4 |
| 4.1 | INTERFACE DESCRIPTION | 4 |
| 4.1.1 | <i>Physical interface</i> | 4 |
| 4.1.2 | <i>Clock stretching</i> | 4 |
| 4.1.3 | <i>Address</i> | 4 |
| 4.2 | INTERFACE PROTOCOL..... | 4 |
| 4.2.1 | <i>Prediction</i> | 7 |
| 4.2.2 | <i>Status Flag</i> | 7 |
| 4.2.3 | <i>Resistance</i> | 7 |
| 5 | APPLICATION INFORMATION | 8 |
| 5.1 | HANDLING INSTRUCTIONS | 8 |
| 5.2 | SOLDERING INSTRUCTIONS..... | 8 |
| 5.3 | TYPICAL APPLICATION | 9 |
| 5.4 | RECOMMENDED FOOTPRINT | 9 |
| 5.5 | ORDERING INFORMATION | 9 |

1 Electrical specifications

1.1 Power supply

| | |
|-------------------|-----------------------------------|
| Voltage | 3.3V \pm 0.1V, max. 20mV ripple |
| Power consumption | max 92.4mW @ 3.3VDC (28mA) |

Note: decoupling capacitor included in design.

1.2 Communication

| | |
|---|--|
| Output signal options | I ² C |
| First functional reading after start up | 15 minutes (can be reduced in specific applications) |

→ For more communication details see chapter 4

2 Environmental specifications

| | |
|-----------------------------|-------------------------------|
| Temperature range operation | 0 to 50°C |
| Temperature range storage | -25 to 50°C |
| Humidity range | 5 to 95 %r.h., non-condensing |

3 Sensor Features

| | |
|--------------------|---|
| Sensing technology | MEMS metal oxide sensor |
| Sensing range | I ² C: 450 – 2000 ppm CO ₂ equivalents (relative) |
| Module | Automatic baseline correction |

4 I²C Interface

4.1 Interface description

4.1.1 Physical interface

The physical interface is two-wire open drain SCL (clock) and SDA (data).

| | |
|-------------------|---|
| Pull-up resistors | External pull-up resistor required |
| Clock speed | 100kHz |
| Clock stretching | Bus master clock stretching support is required |

4.1.2 Clock stretching

Clock stretching pauses a transaction by holding the clock line low. The transaction cannot continue until the line is released to high again. Although the module could send the bytes of data at a fast rate, it could happen that the module is busy at the request time. It can then hold the clock line low after reception and acknowledgement of a byte to force the master into a wait state until the iAQ-core module is ready for the next byte transfer in a type of handshake procedure. (See official I²C specification and user manual UM10204, http://www.nxp.com/documents/user_manual/UM10204.pdf)

4.1.3 Address

Standard 7 bit I²C address for iAQ-core is **decimal 90** or **hexadecimal 0x5A**. The addressing byte includes the read/write bit at the lowest significant bit. The communication with the iAQ-core starts with **0xB5** for reading data.

Please note: avoid addressing the iAQ-core with write bit. This could cause a loss of communication relevant information on modules side and the iAQ-core is no longer contactable.

| | Address | | | | | | | R/ W |
|------|---------|---|---|---|---|---|---|------|
| Bit | 7 | 6 | 5 | 4 | 3 | 2 | 1 | 0 |
| data | 1 | 0 | 1 | 1 | 0 | 1 | 0 | 1 |

Table 1: Addressing byte for the iAQ-core

4.2 Interface protocol

The standard I²C specification is used for the iAQ-core interface protocol. The I²C bus master should request 7 bytes. These seven bytes include information about the indoor air quality value, the iAQ-core status and the resistance of the sensor. If only the indoor air quality value and the status byte is required, the master should request three bytes from the iAQ-core. All bytes are reported back as shown in the following table. A graphical description for a standard I²C communication with the iAQ-core module is shown in figure 2 – figure 5.

| Byte | Name | Data type | Typical/example value | Explanation / notes |
|------|------------|-----------|-----------------------|--|
| 0-1 | pred | uint16 | 450 | Prediction [ppm] |
| 2 | status | uint8 | 0 | 0x00: OK (data valid) 0x01: BUSY (re-read multi byte data!) 0x80: ERROR (if constant:replace sensor) |
| 3-6 | resistance | int32 | 256431 | Sensor resistance [Ohm] |

Table 3: Read data from the iAQ-core




Figure 2: The first byte is send by the master, containing address (0x5A) and read/write bit. The slave sends an acknowledgement (ACK) by pulling the data line to low.




Figure 3: The slave will answer by sending bytes with MSB first. Byte0 and byte1 contain the prediction value. All bytes are Acknowledged by the master.




Figure 4: The third byte contains the information of the iAQ-core module state, in this case status = 1. The master answers with an Acknowledge.




Figure 5: The last four bytes contain the resistance value. For the calculation of the resistance only byte4, byte5 and byte 6 are relevant, because byte3 is zero. After the last requested byte, the master sends a Not Acknowledge.

4.2.1 Prediction

| | | | | | | |
|-------|-------|-------|-------|-------|-------|-------|
| Byte0 | Byte1 | Byte2 | Byte3 | Byte4 | Byte5 | Byte6 |
|-------|-------|-------|-------|-------|-------|-------|

The first two bytes contain the prediction value, which gives the information about the indoor air quality. The value is a CO₂ equivalent and the calculation is shown in the following example.

Equation 1 :

$$\text{Prediction} = \text{byte0} * 2^8 + \text{byte1}$$

4.2.2 Status Flag

| | | | | | | |
|-------|-------|-------|-------|-------|-------|-------|
| Byte0 | Byte1 | Byte2 | Byte3 | Byte4 | Byte5 | Byte6 |
|-------|-------|-------|-------|-------|-------|-------|

The third byte indicates status of the module.

- 0x00: OK
- 0x01: BUSY
- 0x80: ERROR

If status is OK the data is valid. If the status is BUSY, the data integrity is not guaranteed for variables of size > 8 bits, because the module may be updating a part of the variable.

If the status is ERROR constantly (or very frequently) this indicates that the module is reading non-realistic values, and the sensor element is probably defective.

4.2.3 Resistance

| | | | | | | |
|-------|-------|-------|-------|-------|-------|-------|
| Byte0 | Byte1 | Byte2 | Byte3 | Byte4 | Byte5 | Byte6 |
|-------|-------|-------|-------|-------|-------|-------|

The next four bytes contain the sensor resistance in Ohm. Byte3 is always 0.

Equation 2:

$$\text{Resistance} = \text{byte4} * 2^{16} + \text{byte5} * 2^8 + \text{byte6}$$

5 Application Information

5.1 Handling Instructions

The iAQ-core module should be handled carefully, shear stress should be avoided. The sensor is protected by a membrane. This membrane should not be removed or touched.

5.2 Soldering Instructions

For soldering the iAQ-core, standard reflow soldering ovens could be used. The reflow ovens shall be purged with clean air. Other gases must be avoided. For the lead free reflow process a standard process IPC/JEDEC J-STD-020 with peak temperature up to 250°C is suggested. See figure 6 for more detailed description.

Please note: The device shall be kept clear of liquids; therefore a PCB washing process must be avoided in any case.

For manual soldering contact time must be limited to 5seconds at a maximum temperature of 350°C.




Figure 6: Ts min = 150°C; Ts max = 200°C; Ts Preheat = 60-120sec; TL < 220°C for < 150sec; TP <= 250°C for < 30sec; Ramp-up/down speed shall be < 5°C/sec

5.3 Typical Application




Figure 7: Simple microcontroller application

5.4 Recommended footprint




Figure 8: Recommended footprint (standard)

5.5 Ordering information

| Order code | Comment |
|------------|----------|
| 60-0300 | iAQ-core |

Preliminary

AppliedSensor is not responsible for the design, implementation, manufacture or results from use of products that incorporate AppliedSensor components unless expressly agreed to in writing. Prior to using or distributing any product that incorporates AppliedSensor components, users and distributors should assure adequate design, testing and operating safeguards, and consult with AppliedSensor's technical staff, as necessary. All AppliedSensor components and services are sold subject to AppliedSensor's terms and conditions of sale. For the most current AppliedSensor product information and terms and conditions of sale visit us at www.appliedsensor.com. AppliedSensor and the AppliedSensor logo are trademarks of AppliedSensor GmbH and AppliedSensor, Inc. Copyright © 2012 AppliedSensor GmbH. 04.12

AppliedSensor GmbH
Gerhard-Kindler-Str. 8
72770 Reutlingen, Germany
Tel: +49-7121-51486-0
Fax: +49-7121-51486-29

AppliedSensor, Inc.
53 Mountain Boulevard
Warren, NJ 07059, USA
Tel: +1 (908) 222-1477
Fax: +1 (908) 222-1478

AppliedSensor 

www.appliedsensor.com