

NO.	PART NO	DESCRIPTION	QTY
1	255-009201-000	LENS	1
2	273-009201-000	DOUBLE TAPE	1
3	251-009201-000	TOP PANEL	1
4	253-009201-000	REL. KNOB	1
5	245-001804-000	SPRING	1
6	253-009209-000	VOL. KNOB	1
7	254-009201-000	MUTE KNOB	1
8	254-009202-000	DSP KNOB	1
9	254-009203-000	MODE KNOB	1
10	254-009204-000	BND KNOB	1
11	256-009201-000	NUMBER KNOB (CRYSTAL)	8
12	253-009208-000	SEEK KNOB	1
13	271-009201-000	PVC SHEET	1
14	248-009201-900	FILTER SHEET	1
15	253-009205-000	SEEK KONB BL.	1
16	254-009205-000	EJ KNOB	1
17	253-009204-000	VOL. KONB BL.	1
18	253-009202-000	NUMBER KONB ADAPTOR	1
19	288-000202-000	EVA 7.5X7.5X2MM	1
20		SERVER BOARD	1
21		KEY BOARD	1
22	287-009202-000	LCD COVER	1
23	252-009102-400	BOTTOM PANEL	1
24	252-009103-400	BASE	1
25	253-009203-000	HOOK	1
26	245-009101-000	SPRING	1
27		SOCKET PCB	1
28	272-000801-000	PROTECT CLOTHS	1
29	287-009104-000	FRONT DECK BRACKET	1
30		DECK	1
31	242-001803-000	DUSTPROOF CLOTH	1
32	287-009101-000	REAR DECK BRACKET	1
33	282-009102-000	TOP COVER	1
34	262-009103-000	BOTTOM COVER	1
35	242-001801-000	DUSTPROOF CLOTH	1
36		MAIN BOUARD	1
37	287-000801-000	HOOK	2
38	262-009102-000	FRONT RECKET	1
39	262-009101-000	REAR BRACKET	1
40	253-000010-000	WIRE CLIP	2
41	283-009101-000	AL	1
42	262-000804-000	MOUNTING BOX	1

